

Thermal Imaging Scope User Manual



Function

1. Switch On

The camera will be switched on by pressing the power button for 3 seconds in the condition of camera is off, the indicator light will be turned on, and the startup screen will be shown on the internal ocular.

2. Switch Off

The camera will be switched off by depressing the power button for 3 seconds in the condition of camera is on.


The camera will be switched off automatically if there is no operation when in standby mode.

3. Standby

Short Press the power button when the camera is on, it will enter into standby mode with indicator light flickering. Short press again to resume from standby mode to normal mode.

4. Switch the Image Mode

Short click the Image Mode button to switch the image mode when the camera is on. The image mode will be switched from White hot-Black Hot-Hot-Red Hot-Pseudo color circularly.



5. LED Torch

The camera can be used as a torch. the LED can be turned on by long pressing the Image Mode button in the condition of camera is off.

6. E-Zoom

Short click the E-zoom button when the camera is on. The image will be electrical zoomed from 1x-2x-4x circularly.



7. Diopter Adjustment

The diopter knob can help user getting the clearest image for different eye conditions.

8. Setting Menu

Press the E-zoom key to enter the menu, the menu option can be moved up and down with the Image Mode and Photo Capture button.

Short press the key to adjust the current zoom option settings, such as the brightness of the screen, analog video switch, calibration mode selection, restore factory settings, etc..

Long press the E-zoom button to quit the menu after the settings are finished.



setting menu

9. Video Out

Open the analog video through the menu, the down-right corner of the image will have a video output icon displayed, and then the analog video can be output to the monitor with the specific video cable through the USB port.



video output

11. NUC (non-uniformity correction)

Image degradation can be improved by manual correction. There are two correction options available-B and S, it can be changed through the menu. Press the E-zoom and picture button at the same time to make the manual correction.

If the correction mode B is selected, the lens cover is needed to be covered when the correction is performed.

Remove the lens cover after the correction is done.

12. Charge

When the indicator is red, it indicates that the battery is insufficient, please charge in time.

Open the USB cover, and plug the USB cable to charge.

When charging, the indicator light is yellow and it will turn into green when it is fully charged.